

Features:

- Designed for use with FLEXnet DC system monitoring device
- DC current shunt kits provide valuable insight into the status of batteries and DC power source
- One shunt kit is included with FLEXware 500 and FLEXware 1000 DC enclosures

FLEXware Current Shunts Specifications

02/2019

Мос	Description	Includes
FW-SHUNT2	250ADC 25mV current shunt with terminal bus bar for mounting on top of FXR Series inverter/charger	Shunt, mounting hardware & terminal bus bar for connection to FXR inverter/charger DC negative terminal
FW-SHUNT5	O 500ADC 50mV current shunt with terminal bus bar	Shunt, terminal bus bar & one white insulator and mounting screws

Preliminary specifications are subject to change. 980-0061-01-00 REV A